

Bronze Badge Requirements

Cross-Country Readiness

Applicant Must:

- Complete the ABC Training Program with the C Badge Awarded.
- Log at Least 15 Solo Hours in Gliders. This Time Must Include 30 Solo Flights with at Least 10 Flights Flown in a Single-Place Glider if Possible.
- Log at Least 2 Flights, Each Having Duration of Two Hours or More.
- Perform at Least 3 Solo Spot Landings in a Glider Witnessed by an SSAI. The Accuracy and Distance Parameters Established Should be Based on Glider Performance Data, Current Winds, Runway Surface, and Density Altitude. As a Guideline, a Maximum Distance of 400 Feet Would be Acceptable for a Schweizer 2-33 Glider.
- Log Dual Time in Gliders with an Instructor during which at Least 2 Accuracy Landings are Made without Reference to the Altimeter to Simulate Off-field Landings.
- Pass a Closed Book Written Examination Covering Cross-country Techniques and Knowledge. The Minimum Passing Score is 80%. This Examination is Administered Only by an SSAI.